

WEATHERED MEMBRANE CLEANER

GENERAL:

Classic Bond's Weathered Membrane Cleaner is used to clean both new and in-service EPDM membrane and Sure-Weld® membrane prior to the welding process. It helps to loosen and remove dirt and other contaminants from the surface of the EPDM.

TYPICAL PROPERTIES AND CHARACTERISTICS: *

| | |
|----------------------|---|
| Color: | Clear |
| Flash Point: | 55°F (13°C) |
| Solubility in Water: | Negligible |
| Boiling Point: | 246°F (119°C) |
| Packaging: | 5-gallon (18.9 L) & 2 x 1-gallon (3.8 L) closed top cans. |

CAUTIONS AND WARNINGS:

1. **WARNING! HARMFUL IF SWALLOWED. FLAMMABLE LIQUID. MAY BE IRRITATING TO SKIN AND EYES.**
2. Wash thoroughly after handling. Avoid contact with eyes, skin and clothing. Use of solvent resistant gloves and safety glasses recommended. Keep away from heat, sparks, motors and open flame. **DO NOT SMOKE WHILE USING.** Keep lid closed when not in use. Keep out of reach of children.
3. If swallowed, **DO NOT INDUCE VOMITING.** Call physician immediately. In case of eye contact, flush with water for at least 15 minutes. In case of skin contact, wash with soap and water. If irritation develops, call physician.
4. In case of fire handle as a solvent or gasoline fire. Use dry chemical, carbon dioxide or foam fire extinguishers. Water fog or spray may be used to smother the fire and cool containers. Do not use a solid stream of water to fight fire because it can scatter and spread the fire.

COVERAGE RATE:

Depends on the age of the membrane and the amount of dirt and debris on the surface. Assume 400 square feet (121 m²) (one surface) per gallon.

TECHNICAL DATA BULLETIN

CLASSICBOND: WEATHERED MEMBRANE CLEANER

APPLICATION: **

For EPDM:

1. Remove as much loose material as possible from the membrane surface where the adhesive or pressure sensitive product will be applied by brooming or wiping the area with a dry rag. Extreme conditions of accumulated dirt may require detergent and water cleaning (rinse area thoroughly with CLEAN water and allow to dry).
2. Saturate a clean HP Splice Wipe (or equivalent) with Weathered Membrane Cleaner. SCRUB the area in a circular motion. Continue to clean the area, changing wipes frequently, until the surface is a consistent matte black color with no streaking. Additional cleaning is required at factory seams (scrub parallel to the seam). Allow to dry.
3. Primer according to product instructions and/or roofing system specification.